



## SafePak DK-1 Depository Kiosk

The SafePak DK-1 Depository stores deposited bags in lower chest area. Two high-security keys must be used at the same time to open the chest door. A key cannot be removed while the lock is in the unlocked position.

When collecting deposits, first, print a Deposit Manifest. Enter an ID code (“####”) on the keypad...and then enter the Manifest code (“####”) and press “A”. All deposit information will be gathered and automatically printed on the manifest. Deposit information will include individual deposit information and an overall summary. Put the deposit manifest with the bags that were collected.

## How To Collect Deposits



1. Enter ID code.



2. Enter manifest code.




3. Take manifest.



4. Unlock chest door.



5. Remove deposits.



6. Re-lock chest door.

Questions? Problems? Call \_\_\_\_\_